O P E R A T I O N S MAINTENANCE MANUAL

DRAWER WARMERS

CAFE SERIES & RESTAURANT SERIES

WITTCO MODEL NUMBERS

200-1R-C	200-1R
200-2R-C	200-2R
200-3R-C	200-3R
200-4R-C	200-4R
200-1R-BI-C	200-1R-BI
200-2R-BI-C	200-2R-BI
200-3R-BI-C	200-3R-BI
200-4R-BI-C	200-4R-BI





LIMITED WARRANTY

Wittco warrants the Products that it manufactures to be free from defects in materials and workmanship, under normal use and service, for the periods indicated below from the date of purchase when installed and maintained in accordance with Wittco's written instructions. Buyer must establish the "Products" purchase date by returning Wittco's Warranty registration Card or by other means satisfactory to Wittco in its sole discretion.

Wittco warrants its Products to be free from defects in materials and workmanship from the date of purchase (subject to the foregoing conditions) for the period(s) of time and on the conditions listed below:

- a) Ninety (90) days Labor Warranty
- b) One (1) Year Parts Warranty

THE FOREGOING WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR PATENT OR OTHER INTELLECTUAL PROPERTY RIGHT INFRINGEMENT. Without limiting the generality of the foregoing, SUCH WARRANTIES DO NOT COVER: Coated incandescent light bulbs or heat lamps, all glass components, Product misuse, tampering, misapplication, application of improper voltage, or recalibration of thermostats or high limit switches.

LIMITATION OF REMEDIES & DAMAGES

Wittco's liability and Buyer's exclusive remedy hereunder will be limited solely, at Wittco's option, to repair or replacement by a Wittco authorized service agency (other than where Buyer is located outside of the United States or Canada, in which case Wittco's liability and Buyer's exclusive remedy hereunder will be limited solely to replacement of part under warranty) with respect to any claim made within the applicable warranty period referred to above. Without limiting the generality of the foregoing, all portable Products, as defined by Wittco, shall be delivered by Buyer, at its sole expense, to the nearest Wittco authorized service agency for replacement or repair. Wittco reserves the right to accept or reject any such claim in whole or in part. Wittco will not accept the return of any Product without prior written approval from Wittco, and all such approved returns shall be made at Buyer's sole expense. WITTCO WILL NOT BE LIABLE, UNDER ANY CIRCUMSTANCES, FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, INCLUDING BUT NOT LIMITED TO LABOR COSTS OR LOST OF PRODUCTS AND LOSS OF PROFITS RESULTING FROM THE USE OF OR INABILITY TO USE THE PRODUCTS.



WITTCO TECHNICAL & PRODUCT SUPPORT

TECHNICAL SUPPORT & SERVICE INQUIRES MAY BE DIRECTED TO WITTCO BY:

1. CALLING DIRECTLY TO:

WITTCO FOODSERVICE EQUIPMENT TECHNICAL & SERVICE DEPARTMENT - (800) 367-8413 8:00 AM - 4:30 PM (CENTRAL TIME)

2. FAXING DIRECTLY TO:

WITTCO FOODSERVICE EQUIPMENT TECHNICAL & SERVICE DEPARTMENT - (414) 354-2821 DAILY 24 HOURS

3. MAILING DIRECTLY TO:

WITTCO FOODSERVICE EQUIPMENT INC. 7737 NORTH 81ST. STREET MILWAUKEE, WISCONSIN 53223 USA

WHEN DIRECTING INQUIRIES TO WITTCO PLEASE HAVE THE FOLLOWING INFORMATION AVAILABLE TO AVOID DELAYS

- 1. Wittco model number indicated on the equipment serial data plate located at the electrical connection.
- Wittco serial number indicated on the equipment serial data plate. The equipment serial number will also have two (2) alpha characters immediately following the serial number. These alpha characters are part of the serial number.



INTRODUCTION

The 200 series of drawer warmers from Wittco Foodservice Equipment provide an efficient and sanitary method of holding a variety of hot prepared foods.

This manual has been produced to provide persons responsible for the operation and maintenance of the equipment with a simple but comprehensive understanding of its proper use and care. We recommend that this manual be read and understood prior to placing the unit into operation.

NOTE: THE DRAWER WARMER SHOULD BE THOROUGHLY CLEANED IN ACCORDANCE WITH THE INSTRUCTIONS CONTAINED IN THIS MANUAL PRIOR TO PUTTING INTO SERVICE.

It is recommended that prior to placing the drawer warmer into operation that it be pre-heated at the highest temperature setting for period of 30-45 minutes.

Should repair or adjustment of the unit become necessary, we suggest that procedures described in this manual be followed. The operator may also contact the authorized Wittco dealer who sold the product or an authorized Wittco service agency. If the needed repair occurs during the warranty period, prior authorization is required from Wittco by the service company before the work is commenced.

It is our sincere desire that you obtain the maximum benefit from your Wittco heated drawer warmer system. If at any time questions arise or additional information is required, contact Wittco ar 800 367-8413.

DESCRIPTION

The Wittco 200 series of drawer warmers provide an efficient means of holding a variety of prepared hot food products at proper temperatures until serving. The 200-R series is provided with a large 15 X 20 over-sized drawer insert and the 200-C series with a standard 12 X 20 X 4 steam table pan insert.

UNCRATING

Each Wittco drawer warmer system is packed in a cardboard carton, which in turn is banded to a wooden pallets. When the unit is received by the operator, the carton should immediately be inspected for any sign of visible exterior damage to the carton. If the carton is punctured or dented, it many be an indication that the unit has sustained concealed freight damage.

It is very important that any evidence of damage be noted on the Bill of Lading at the time of receipt.

UNPACKING THE UNIT

- 1. Remove the banding material holding the carton to the pallet.
- 2. Remove the cardboard carton and the plastic bag covering the unit.
- 3. Carefully lift the unit off the carton bottom and pallet and place it on the floor or table.
- 4. Remove the legs for the unit located in the drawer of the unit.
- 5. Secure the legs to the bottom of the drawer warmer by screwing the legs into the holes provided.
- 6. Remove any and all packaging materials in the drawers.
- 7 Thoroughly clean the unit as described in the instructions.

ELECTRICAL REQUIREMENTS

The 200 drawer warmer series are factory wired for either 110/120 volt or 208/240 volt, single phase operation. All 110/120 volt units are equipped with a 6 foot cord and NEMA 5-15 plug as standard equipment. All 208/240 volt units are equipped with a 6 foot cord and NEMA 5-15 plug (200-1R & 1C; 200-2R & 2C; 200-3R & 3C) and a NEMA 6-20 plug (200-4R & 4C)

CAUTION: Verify that the power source matches the data plate on the lower rear corner of the unit and the plug configuration before the connection is made.

OPERATION

The control panel of the 200 series contains an operating indicator light and full range thermostat.

Once the unit has been connected to the appropriate power source the unit is ready for operation. the operating thermostat also acts as the on/off switch to the drawer warmer system. Turning the thermostat counter clock-wise until it stops will turn the system off.

Rotate the thermostat dial so that it points to the number 5. This will cause the heating elements to start heating. When this occurs the red operating indicator light will illuminate. this light will stay on as long as the heating element are engaged. Once the predetermined temperature is achieved, the heating element will begin to cycle. During this period the red operating indicator light will turn on and off as the heating elements cycle.

As the heating elements are heating, the thermometer will begin to move and indicate the interior temperature of the cabinet. At the number 5 setting the thermometer should indicate an average temperature of approximately 150 degrees F.

NOTE: The temperature in any heated unit will fluctuate as the heating element cycle on and off. The thermostat setting will provide an average temperature in the unit. However, the operator should always monitor the food product to insure that it remains at proper temperatures.

REMEMBER - THE GREATER THE THERMOSTAT NUMBER SETTING THE HIGHER THE UNIT TEMPERATURE AND THE LOWER THE THERMOSTAT NUMBER SETTING THE LOWER THE CABINET TEMPERATURE.

CLEANING

The interior drawer inserts of the unit should be cleaned prior to putting unit into service. Use a mild soap and water solution to clean. Never use harsh chemicals or abrasive pads to clean the unit.

REPLACEMENT OF ELECTRICAL COMPONENTS

It is highly recommended that only Wittco Foodservice Equipment replacement parts be used to insure compatibility of component parts in the operation of the drawer warmer system.

THERMOSTAT/SENSING BULB REPLACEMENT

- 1. DISCONNECT THE UNIT FROM ITS POWER SOURCE.
- 2. Remove the black thermostat control knob from the control panel by loosening the "Lend" screws that hold it to the thermostat stem.
 - NOTE: PRIOR TO LOOSENING THE "L-END" SCREWS, TURN THE BLACK THERMOSTAT KNOB SO THAT THE ARROW ON THE KNOB IS IN THE "OFF" POSITION.
- 3. Remove the control panel from its housing by removing the control panel retaining screws and gently pulling the control panel forward exposing the back side of the control panel.
- 4. Notice the arrangement and connection of all electrical leads and refer to the wiring diagrams for reference.
- 5. Disconnect the wire leads connected to the thermostat.
- 6. Remove the entire drawer from the unit exposing the temperature sensing bulb..
- 7. Loosen the screws holding the temperature sensing bulb to the interior drawer compartment.
 - NOTE: The temperature sensing bulb must be replaced whenever the thermostat is replaced. The temperature sensing bulb lead wire is permanently connected to the thermostat.
- 8. Remove the screws holding the thermostat to the control panel.

- 9. Gently pull the temperature sensing bulb lead wire through the access hole and remove entire thermostat.
- 10. Install the replacement thermostat and temperature sensing bulb following the reverse order of the above procedure.
- 11. Reinstall the control panel to the unit.
- 12. Reconnect the unit to its power source and test.

HEATING ELEMENT REPLACEMENT

1. DISCONNECT THE UNIT FROM ITS POWER SOURCE.

- 2. Remove the entire drawer from the unit exposing the heating element.
- 3. Remove the element retaining screws securing the element to the floor of the drawer compartment.
- 4. Remove the element retaining screws securing the element housing to the rear of the drawer compartment.
- 5. Gently pull the element from its housing exposing the heated element wire connectors.
- 6. Disconnect the element connectors.
- 7. Install the replacement heating element following the reverse of the above steps.
- 8. Reinstall the drawer to its compartment by following the revere of the above.
- 9. Reconnect the unit to its power source and test.

INDICATOR LIGHT REPLACEMENT

1. DISCONNECT THE UNIT FROM ITS POWER SOURCE.

- 2. Remove the retaining screws holding the control panel to the unit.
- 3. Remove the control panel from its housing gently pulling the control panel forward exposing the back side of the control.
- 4. Notice the arrangement and connection of all electrical leads and refer to the wiring diagrams for reference.


- 5. Disconnect the wire leads connected to the indicator light.
- 6. Remove the indicator light from the control panel.
- 7. Install the replacement indicator light into the control panel. The indicator will snap into the control from the front.
- 8. Reinstall the control panel by following the reverse of the above.
- 9. Reconnect the units to its power source and test.

THERMOMETER REPLACEMENT


- 1. Remove the drawer assembly containing the defective thermometer.
- 2. Remove the defective thermometer by removing the retaining clip located on the back side of the drawer assembly.
- 3. Install the replacement thermometer.
- 4. Reinstall the drawer assembly into the drawer compartment.

DRAWER SLIDE REPLACEMENT


- 1. Remove the drawer assembly containing the defective drawer slide(s).
- 2. Note the configuration of the drawer slides. The left and right drawer slides are specific to each respective side.
- 3. Remove the defective drawer slides by lifting the slides off of the stainless steel rollers.
- 4. Install the replacement drawer slides in the same order as they were removed.
- 5. Reinstall the drawer assembly.


















WITTCO FOODSERVICE EQUIPMENT INC. REPLACEMENT PARTS LIST

WITTCO SERIES - DRAWER WARMERS - RESTAURANT SERIES

WITTCO	SERIES - DRAWER WARMERS - RESTAURAN		UMBER AND	QUANTITY	6/18/98 REQUIRED
PART NO.	PART DESCRIPTION	200-1R	200-2R	200-3R	200-4R
WP-114-2R	CASTER 2" HEAVY DUTY RIGID	2	2	2	2
WP-114-2S	CASTER 2" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-3R	CASTER 3" HEAVY DUTY RIGID	2	2	2	2
WP-114-3S	CASTER 3" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-4R	CASTER 4" HEAVY DUTY RIGID	2	2	2	2
WP-114-4S	CASTER 4" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-5R	CASTER 5" HEAVY DUTY RIGID	2	2	2	2
WP-114-5S	CASTER 5" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-6R	CASTER 6" HEAVY DUTY RIGID	2	2	2	2
WP-114-6S	CASTER 6" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-6IIR	CASTER 6" HI-MODULUS RIGID	2	2	2	2
WP-114-6HS	CASTER 6" HI-MODULUS SWIVEL W/BRAKE	2	2	2	2
WP-146-4	CONTROL PANEL DECAL (BLUE)	1	2	3	4
WP-052	CORD, 8 FT.	1	1	1	
WP-247	CORD, HEAVY DUTY (20 AMP)				1
WP-204	DOLLY CART W/5" CASTERS	1	1	1	1
WP-156A	DRAWER ASSEMBLY COMPLETE	1	2	3	4
WP-156B	DRAWER ASSEMBLY (NO HARDWARE)	1	2	3	4
WP-156C	DRAWER FRAME ONLY (NO FRONT PANEL)	1	2	3	4
WP-156	DRAWER FRONT PANEL ONLY (NO HARDWARE)	1	2	3	4
WP-131	DRAWER HUMIDITY GRID	1	2	3	4
WP-152	DRAWER MOIST/CRISP SLIDE W/KNOB	1	2	3	4
WP-272	DRAWER MOIST/CRISP SLIDE KNOB (ONLY)	1	2	3	4
WP-153	DRAWER PAN 15x20x5" DEEP	1	2	3	4
WP-117	DRAWER PULL HANDLE W/DECAL	1	2	3	4
WP-321	DRAWER PULL HANDLE DECAL (BLUE)	1	2	3	4
WP-081	DRAWER ROLLERS (BEARING TYPE)	8	16	24	32
WP-053	DRAWER SLIDES (Pr.) LH & RH	1	2	3	4

WITTCO		MODEL N	JMBER AND	QUANTITY	REQUIRED
PART NO.	PART DESCRIPTION	200-1R	200-2R	200-3R	200-4R
WP-003-1	ELEMENT: 475 WATT 120 VOLT	1	2	3	4
WP-003-2	ELEMENT, 475 WATT 208-240 VOLT	1	2	3	4
WP-022-5	LEGS, 4" TO 5 ½ " ADJUSTABLE	4	4	4	4
WP-040	LIGHT, INDICATOR ROUND 125 VOLT	1	2	3	4
AD-226-0000-0	LIGHT, INDICATOR ROUND 250 VOLT	1	2	3	4
WP-006-1	STRAIN RELIEF AT POWER CORD	1	1	1	
WP-006-6	STRAIN RELIEF AT POWER CORD (METAL) STRAIGHT				1
WP-008	THERMOMETER, DIAL TYPE	1	2	3	4
WP-155	THERMOMETER BULB HOLDER	1	2	3	4
WP-110	THERMOSTAT, W/OUT KNOB	1	2	3	4
WP-242	THERMOSTAT KNOB	1	2	3	4
WP-089	THERMOSTAT BULB HOLDER	2	4	6	8
WP-308-1R	TOP COVER	1	1	1	1

WITTCO FOODSERVICE EQUIPMENT INC. REPLACEMENT PARTS LIST

WITTCO SERIES - DRAWER WARMERS - CAFE SERIES

WITTCO	SERIES - DRAWER WARMERS - CAPE SERIES	MODEL NU	JMBER AND	QUANTITY	REQUIRED
PART NO.	PART DESCRIPTION	200-1R-C	200-2R-C	200-3R-C	200-4R-C
WP-114-2R	CASTER 2" HEAVY DUTY RIGID	2	2	2	2
WP-114-2S	CASTER 2" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-3R	CASTER 3" HEAVY DUTY RIGID	2	2	2	2 .
WP-114-3S	CASTER 3" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-4R	CASTER 4" HEAVY DUTY RIGID	2	2	2	2
WP-114-4S	CASTER 4" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-5R	CASTER 5" HEAVY DUTY RIGID	2	2	2	2
WP-114-58	CASTER 5" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-6R	CASTER 6" HEAVY DUTY RIGID	2	2	2	2
WP-114-6S	CASTER 6" HEAVY DUTY SWIVEL W/BRAKE	2	2	2	2
WP-114-6HR	CASTER 6" HI-MODULUS RIGID	2	2	2	2
WP-114-6HS	CASTER 6" HI-MODULUS SWIVEL W/BRAKE	2	2	2	2
WP-146-4	CONTROL PANEL DECAL (BLUE)	1	2	3	4
WP-052	CORD, 8 FT.	1	1	1	
WP-247	CORD, HEAVY DUTY (20 AMP)				1
WP-204	DOLLY CART W/ 5" CASTERS	1	1	1	1
WP-156A	DRAWER ASSEMBLY COMPLETE	1	2	3	4
WP-156B	DRAWER ASSEMBLY (NO HARDWARE)	1	2	3	4
WP-156C	DRAWER FRAME ONLY (NO FRONT PANEL)	1	2	3	4
WP-156	DRAWER FRONT PANEL ONLY (NO HARDWARE)	1	2	3	4
WP-152	DRAWER MOIST/CRISP SLIDE W/KNOB	1	2	3	4
WP-272	DRAWER MOIST/CRISP SLIDE KNOB (ONLY)	1	2	3	4
WP-200	DRAWER PAN 12x20x4" DEEP	1	2	3	4
WP-117	DRAWER PULL HANDLE W/DECAL	1	2	3	4
WP-321	DRAWER PULL HANDLE DECAL (BLUE)	1	2	3	4
WP-081	DRAWER ROLLERS (BEARING TYPE)	8	16	24	32
WP-053	DRAWER SLIDES (Pr.) LH & RH	1	2	3	4

WITTCO		MODEL N	UMBER AND	QUANTITY	REQUIRED
PART NO.	PART DESCRIPTION	200-1R-C	200-2R-C	200-3R-C	200-4R-C
WP-003-1	ELEMENT, 475 WATT 120 VOLT	1	2	3	4
WP-003-2	ELEMENT. 475 WATT 208-240 VOLT	1	2	3	4
WP-022-5	LEGS, 4" TO 5 ½ " ADJUSTABLE	4	4	4	4
WP-040	LIGHT, INDICATOR ROUND 125 VOLT	1	2	3	4
AD-226-0000-0	LIGHT, INDICATOR ROUND 250 VOLT	1	2	3	4
WP-006-1	STRAIN RELIEF AT POWER CORD	1	1	1	
WP-006-6	STRAIN RELIEF AT POWER CORD (METAL) STRAIGHT				ı
WP-008	THERMOMETER, DIAL TYPE	1	2	3	4
WP-155	THERMOMETER BULB HOLDER	1	2	3	4
WP-110	THERMOSTAT, W/OUT KNOB	1	2	3	4
WP-242	THERMOSTAT KNOB	1	2	3	4
WP-089	THERMOSTAT BULB HOLDER	2	4	6	8
WP-308-1R	TOP COVER	1	1	1	1
					_

WITTCO FOODSERVICE EQUIPMENT INC. REPLACEMENT PARTS LIST

WITTCO SERIES - DRAWER WARMERS - CAFE SERIES (BUILT - IN)

WITTCO		MODEL	NUMBER AND	QUANTITY RE	QUIRED
PART NO.	PART DESCRIPTION	200-1R-C-BI	200-2R-C-BI	200-3R-C-BI	200-4R-C-BI
WP-146-4	CONTROL PANEL DECAL (BLUE)	1	2	3	4
WP-269	CORD CONNECTOR & BX CABLE	1	1	1	
WP-156A	DRAWER ASSEMBLY COMPLETE	1	2	3	4
WP-156B	DRAWER ASSEMBLY (NO HARDWARE)	1	2	3	4
WP-156C	DRAWER FRAME ONLY (NO FRONT PANEL)	1	2	3	4
WP-156	DRAWER FRONT PANEL ONLY (NO HARDWARE)	1	2	3	4 .
WP-152	DRAWER MOIST/CRISP SLIDE W/KNOB	1	2	3	4
WP-272	DRAWER MOIST/CRISP SLIDE KNOB (ONLY)	1	2	3	4
WP-200	DRAWER PAN 12x20x4" DEEP	1	2	3	4
WP-117	DRAWER PULL HANDLE W/OVERLAY	1	2	3	4
WP-321	DRAWER PULL HANDLE DECAL (BLUE)	1	2	3	4
WP-081	DRAWER ROLLERS (BEARING TYPE)	8	16	24	32
WP-053	DRAWER SLIDES (Pr.) LH & RH	1	2	3	4
WP-003-1	ELEMENT, 475 WATT 120 VOLT	1	2	3	4
WP-003-2	ELEMENT, 475 WATT 208-240 VOLT	1	2	3	4
WP-040	LIGHT, INDICATOR ROUND 125 VOLT	1	2	3	4
AD-226-0000-0	LIGHT, INDICATOR ROUND 250 VOLT	1	2	3	4
WP-006-5	STRAIN RELIEF AT POWER CORD (METAL 90')	1	1	1	
WP-006-6	STRAIN RELIEF AT POWER CORD (METAL) STRAIGHT				1
WP-008	THERMOMETER, DIAL TYPE	1	2	3	4
WP-155	THERMOMETER BULB HOLDER	1	2	3	4
WP-110	THERMOSTAT, W/OUT KNOB	1	2	3	4
WP-242	THERMOSTAT KNOB	1	2	3	4
WP-089	THERMOSTAT BULB HOLDER	2	4	6	8
WP-308-2R	TOP COVER	1	1	1	1
WP-323-1RC	TRIM PANEL	1			

WITTCO		MODEL	NUMBER AND	QUANTITY RE	QUIRED
PART NO.	PART DESCRIPTION	200-1R-C-BI	200-2R-C-BI	200-3R-C-BI	200-4R-C-BI
WP-323-2RC	TRIM PANEL		1		
WP-323-3RC	TRIM PANEL			1	
WP-323-4RC	TRIM PANEL				I
					

WITTCO FOODSERVICE EQUIPMENT INC. REPLACEMENT PARTS LIST

WITTCO SERIES - DRAWER WARMERS - RESTAURANT SERIES (BUILT - IN)

WITTCO	ERIES - DRAWER WARMERS - RESTAU			QUANTITY R	6/18/98 EQUIRED
PART NO.	PART DESCRIPTION	200-1R-BI	200-2R-BI	200-3R-BI	200-4R-BI
WP-146-4	CONTROL PANEL DECAL (BLUE)	1	2	3	4
WP-269	CORD CONNECTOR & BX CABLE	1	1	1	
WP-156A	DRAWER ASSEMBLY COMPLETE	1	2	3	4
WP-156B	DRAWER ASSEMBLY (NO HARDWARE)	1	2	3	4
WP-156C	DRAWER FRAME ONLY (NO FRONT PANEL)	1	2	3	4
WP-156	DRAWER FRONT PANEL ONLY (NO HARDWARE)	1	2	3	4
WP-131	DRAWER HUMIDITY GRID	1	2	3	4
WP-152	DRAWER MOIST/CRISP SLIDE W/KNOB	1	2	3	4
WP-272	DRAWER MOIST/CRISP SLIDE KNOB (ONLY)	1	2	3	4
WP-153	DRAWER PAN 15x20x5" DEEP	1	2	3	4
WP-117	DRAWER PULL HANDLE W/OVERLAY	1	2	3	4
WP-321	DRAWER PULL HANDLE DECAL (BLUE)	1	2	3	4
WP-081	DRAWER ROLLERS (BEARING TYPE)	8	16	24	32
WP-053	DRAWER SLIDES (Pr.) LH & RH	1	2	3	4
WP-003-1	ELEMENT, 475 WATT 120 VOLT	1	2	3	4
WP-003-2	ELEMENT, 475 WATT 208-240 VOLT	1	2	3	4
WP-040	LIGHT, INDICATOR ROUND 125 VOLT	1	2	3	4
AD-226-0000-0	LIGHT, INDICATOR ROUND 250 VOLT	1	2	3	4
WP-006-5	STRAIN RELIEF AT POWER CORD (METAL 90')	1	1	1	
WP-006-6	STRAIN RELIEF POWER CORD (METAL) STRAIGHT				1
WP-008	THERMOMETER, DIAL TYPE	1	2	3	4
WP-155	THERMOMETER BULB HOLDER	1	2	3	4
WP-110	THERMOSTAT, W/OUT KNOB	1	2	3	4
WP-242	THERMOSTAT KNOB	1	2	3	4
WP-089	THERMOSTAT BULB HOLDER	2	4	6	8
WP-197-1	TOP COVER	1	1	1	1

WITTCO		MODEL	NUMBER AND	QUANTITY RE	QUIRED
PART NO.	PART DESCRIPTION	200-1R-BI	200-2R-BI	200-3R-BI	200-4R-BI
WP-323-1RC	TRIM PANEL	1			
WP-323-2RC	TRIM PANEL		1		
WP-323-3RC	TRIM PANEL			1	
WP-323-4RC	TRIM PANEL				1
		_			
				-	

	- NOTES -	
3		
		:
		;

	- NOTES -	
3		
		:
		;

